

Mindball Play - Brainlink Instructions

Setup:

You will need your computer to be able to communicate with the headband(s). This is done via Bluetooth, so your computer must have built in Bluetooth or an USB adapter installed. We highly recommend using any of the adapters recommended here:

<https://www.mindballplay.com/product/mindball-play-headband-brainlink-lite-version-2-0/>

Make sure Bluetooth is activated on your computer. Activate and pair the headbands you want to use.

If you use Mindball Play on more than one computer in the same room/area, it can be helpful to only pair each BrainLink with one of the computers. Otherwise one computer might connect to all headbands, preventing other computers from connecting to the devices.

Usage:

To power on BrainLink, press and hold the button until the unit beeps two times. The indicator light will flash blue when the unit is on.

To power off, press and hold the button for 1 second. When released the unit beeps once. BrainLink headbands that are on and paired will be automatically detect by Mindball Play.

Known problems:

We had some problems with running more than one headband with the default drivers from Windows. We solved this by installing drivers provided by the hardware manufacturer. You may or may not have this problem at all, depending on what Bluetooth USB you're using.

Contact

Are you experiencing problems or have other questions about the game? Don't worry, we'll try to help!

Contact us at:
support@mindballplay.com

Good luck!